

Viewmaster

EN - User guide

DE - Benutzerhandbuch

ES - Manual de usuario

SE - Bruksanvisning

FI - Käyttöohjeet

DK - Betjeningsvejledning

LV - Lietošanas instrukcija

LT - Naudojimo instrukcija

EE - Kasutusjuhend

PL - Instrukcja obsługi

CZ - Uživatelský návod

SK - Manual





FOCUS
BRINGS NATURE CLOSER



Viewmaster





Congratulations on your new spotting scope!



- Never look at the sun, as this can cause damage to your eyes.
- Never leave the spotting scope in the sun, as the light beam through the spotting scope may cause a fire.



- Never disassemble the spotting scope and do not expose it to temperatures above 60°C degrees.



- Clean the optics with a microfiber cloth, for tough dirt use a lens cleaning kit.
- Respect your surroundings and other people's privacy.
- Dispose of the packaging in the appropriate plastic/paper containers.
- Always use a sturdy tripod of high quality, which you can buy at well-assorted spotting scope stores.

Your spotting scope comprise the following parts, see **A** on page 3

1. Eyepiece
2. Focus wheel
3. Sunshade
4. Objective
5. Tripod mounting ring

Viewmaster

EN

Adjusting for best view

- B** Mount the eyepiece by screwing the lock-ring clockwise properly.
- C** Mount your tripod plate (not Included), to the tripod mount ring on the spotting scope.
- D** Adjust the twist-up eyecup to a convenient distance for the best viewing.
- E** Adjust the focusing wheel for best sharpness.
- F** Start with the lowest magnification, it will be easiest way to find your target. Then increase to the desired magnification.
- G** Expand the sunshade if needed by pulling it out. The sunshade also helps to protect the objective from raindrops and fingerprints.
- H** You can easily adjust your viewing angle by loosen the screw on the tripod mounting ring. Turn the screw to the right to secure the spotting scope.
- I & J** Protect your spotting scope with the stay-on case, which is easy to use when mounted.